

Service Manual



Label Printer

XC Q

MADE IN GERMANY

Family	Type
XC Q	XC Q4
	XC Q6.3

Edition: 11/2023 - **Part No.** 9004019

Copyright

This documentation as well as translation hereof are property of cab Produkttechnik GmbH & Co. KG.

The replication, conversion, duplication or divulgement of the whole manual or parts of it for other intentions than its original intended purpose demand the previous written authorization by cab.

Trademark

Windows is a registered trademark of the Microsoft Corporation.

Editor

Regarding questions or comments please contact cab Produkttechnik GmbH & Co. KG.

Topicality

Due to the constant further development of our products discrepancies between documentation and product can occur. Please check www.cab.de for the latest update.

Terms and conditions

Deliveries and performances are effected under the General conditions of sale of cab.

Further documentation

Configuration Manual cab Printers

▷ <https://www.cab.de/media/pushfile.cfm?file=3257> 

Programming Manual cab Printers

▷ <https://www.cab.de/media/pushfile.cfm?file=3047> 



Germany
cab Produkttechnik GmbH & Co KG
Karlsruhe
Phone +49 721 6626 0
www.cab.de

USA
cab Technology, Inc.
Chelmsford, MA
Phone +1 978 250 8321
www.cab.de/us

Taiwan
cab Technology Co., Ltd.
Taipei
Phone +886 (02) 8227 3966
www.cab.de/tw

Singapore
cab Singapore Pte. Ltd.
Singapore
Phone +65 6931 9099
www.cab.de/en

France
cab Technologies S.à.r.l.
Niedermörsen
Phone +33 388 722501
www.cab.de/fr

Mexico
cab Technology, Inc.
Juárez
Phone +52 656 682 4301
www.cab.de/es

China
cab (Shanghai) Trading Co., Ltd.
Shanghai
Phone +86 (021) 6236 3161
www.cab.de/cn

South Africa
cab Technology (Pty) Ltd.
Randburg
Phone +27 11 886 3580
www.cab.de/za

Table of Contents

1	Introduction	4
1.1	Instructions.....	4
1.2	General Safety Instructions.....	4
1.3	Protective Devices	5
1.4	Handling Electricity	5
1.5	Procedure in Case of Accidents	5
1.6	Environment.....	5
2	Tools.....	6
3	Replacing Assembly Units	7
3.1	Replacing the Printhead.....	7
3.2	Replacing the Print Rollers.....	9
3.3	Replacing the Slipping Clutches	10
3.4	Replacing the Label Sensor	12
3.5	Replacing the PCB CPU	13
3.6	Replacing the Power Supply Unit.....	14
4	Adjustments	15
4.1	Measuring and Adjusting the Winding Torques	15
4.1.1	Measuring the Winding Torques	15
4.1.2	Adjusting the Winding Torques	17
4.2	Adjusting the Media Feed Path	18
4.3	Adjusting the Printing Mechanism.....	19
4.3.1	Preparing the Printer for Adjustment	19
4.3.2	Aligning the Printhead to the Print Roller.....	20
4.3.3	Adjusting the Printhead Pressure.....	21
4.3.4	Adjusting the Transfer Ribbon Feed Path.....	21
4.3.5	Final Test	22
4.4	Adjusting the Automatic Ribbon Saver.....	23
4.4.1	Setting the Eccentrics.....	23
4.4.2	Adjusting the Magnetic Clutch.....	24
5	Troubleshooting and Error Treatment.....	25
5.1	Failure of Device Functions.....	25
5.2	Permanent Hardware Faults	25
6	Block Diagram	26
7	Layout Diagram CPU	27
8	Index.....	28

1.1 Instructions

Important information and instructions in this documentation are designated as follows:



Danger!

Draws attention to an exceptionally great, imminent danger to your health or life due to hazardous voltages.



Danger!

Draws attention to a danger with high risk which, if not avoided, may result in death or serious injury.



Warning!

Draws attention to a danger with medium risk which, if not avoided, may result in death or serious injury.



Caution!

Draws attention to a danger with low risk which, if not avoided, may result in minor or moderate injury.



Attention!

Draws attention to potential risks of property damage or loss of quality.



Note!

Advices to make work routine easier or on important steps to be carried out.



Environment!

Gives you tips on protecting the environment.



Handling instruction



Reference to section, position, illustration number or document.



Option (accessories, peripheral equipment, special fittings).

Time

Information in the display.

1.2 General Safety Instructions

This service manual is intended for use by qualified service and maintenance personnel. For more operation and configuration information, refer to the user or configuration manual.

Follow the general safety rules below:

- Keep the area around the device clean at all times!
- Work with safety in mind.
- Parts of device that are removed during the maintenance work must be put in a safe place.
- Avoid risks of tripping over.



Danger!

Double pole/neutral fusing.



Danger!

Danger to life and limb from increased current flow through metal parts in contact with the device.

- ▶ Do not wear clothing with metal parts.
- ▶ Do not wear jewelry.
- ▶ Do not wear spectacles with metal frames.



Warning!

Items of clothing drawn into the device by moving parts can lead to injuries.

- ▶ Do not wear any items of clothing which could get caught by moving parts.

1.3 Protective Devices

**Warning!**

There is a risk of injury if protective devices are missing or defective.

- ▶ Replace all protective devices (covers, safety notices, grounding cables etc) after maintenance work has been completed.
- ▶ Replace parts that have become defective or unusable.

Wear protective goggles for:

- Knocking pins or similar parts in or out with a hammer.
- Using spring hooks.
- Inserting or removing springs, retaining rings or grip rings.
- Using solvents, cleansers or other chemicals.

1.4 Handling Electricity

The following work may only be done by trained and qualified electricians:

- Work on electrical components.
- Work on an open device still connected to the mains supply.

General precautions before starting maintenance work:

- Find out where the emergency and power switches are so that they can be quickly thrown in an emergency.
- Disconnect the current supply before carrying out the following work:
 - Installing or removing power units.
 - Working in the immediate vicinity of open power supply components.
 - Mechanical check of power supply components.
 - Modifying circuits in the device.
- Test the zero potential of the device parts.
- Check the working area for possible sources of danger, such as wet floors, defective extension cables, defective protective conductor connections.

Additional precautions in the case of exposed voltages:

- Ask a second person to remain near the working site. This person must know where the emergency and power switches are, and how to switch the current off if danger arises.
- Only use one hand to work on electric circuits of devices that are switched on. Keep the other hand behind your back or in your pocket.
This prevents electricity from flowing through your own body.

1.5 Procedure in Case of Accidents

- Act calmly and with great care.
- Avoid danger to yourself.
- Switch off power.
- Request medical assistance.
- Give first aid, if necessary.

1.6 Environment



Obsolete assemblies contain valuable recyclable materials that should be sent for recycling.

- ▶ Send to suitable collection points, separately from residual waste.
- ▶ Send the parts for recycling.

- ▶ Do not use any worn or damaged tools.
- ▶ Only use tools and testing devices that are suitable for the task at hand.

cab special tools:

- Test collar for transfer ribbon winder (cab Part-No. 5540932)
- Distance caliber 0,1 mm (cab Part-No. 5961064)

Standard tools:

- Screw driver Torx, size TX 10, TX 20
- Allen key 1,5 mm
- Allen key 2,5 mm (included)
- Phillips-head screwdriver, size 1
- Snap ring pliers ZGG 0
- Snap ring pliers ZGG 1
- Cylindrical dynamometer (spring scale), 0 - 10 N
- Scale Magnifier
- Digital Circuit Analyzer

3.1 Replacing the Printhead

The printhead of the label printer can be replaced without the need for fine adjustment.




Figure 1 Structure of the printhead

1. Data connector
2. Power connector
3. Threaded holes
4. Catching holes
5. Heating line



Attention!

The printhead can be damaged by static electricity discharges and impacts!

- ▶ Set up printer on a grounded, conductive surface.
- ▶ Ground your body, e.g. by wearing a grounded wristband.
- ▶ Do not touch contacts on the plug connections (1, 2).
- ▶ Do not touch heating line (5) with hard objects or your hands.




Figure 2 Replacing the printhead



Note!

The replacement of the printhead will be described for Printhead 2 (upper printhead). On print head 1 (bottom), the plungers of the head pressure system must be pushed inwards. The work steps then also apply in an analogous manner to print head 1 (below).

- Loosen screws (6) and remove the discharge brushes (7).

Dismounting the Printhead

1. Remove the media from the printer.
2. Lock the printhead.
3. Loosen two screws (8).
4. Open the printhead locking and if necessary remove the printhead from the pins (11).
5. First unplug the power cable (10), followed by the data cable (9).

Mounting the Printhead

1. First connect the data cable (9), followed by the power cable (10).
2. Place the printhead into the printhead assembly and insert the pins (11) into the holes (4).
3. Hold the printhead carriage lightly on the printing roller with one finger and check that the print head is correctly positioned in the printhead carriage.
4. Fix the printhead with the screws (8) at the carriage using the threaded holes (3).
5. Clean the heating line with the cleaning cloth included in the contents of delivery.
6. Reload labels and transfer ribbon.

3.2 Replacing the Print Rollers




Figure 3 Replacing print rollers

**Note!**

The replacement of both print rollers (2) can be done in the same manner.

1. Open the locking system
2. Pivot the printhead away from the roller.
3. Loosen screw (4).
4. Remove ball bearing (3) and roller (2) through the side plate.
5. Guide the new roller through the side plate to the axle (1). Turn the roller to align it to the hexagonal end of the axle and push the roller further until it stops.
6. Insert the ball bearing (3) in to the side plate and fix it with screw (4).

3.3 Replacing the Slipping Clutches

The rewinders for the transfer ribbon are coupled with slipping clutches to the main drive. The supply hubs of the transfer ribbon are braked with slipping clutches during printing.

Replace a slipping clutch when the set value of the torque cannot be set

▷ 4.1.2 on page 17.

Removal and installation of the slipping clutch is also required for replacement of a winder.




Figure 4 Slipping clutches




Danger!

Risk of death via electric shock!

- ▶ Before opening the housing cover, disconnect the device from the mains supply and wait at least one minute until the power supply unit has discharged.

Replacing the Slipping Clutches at the Rewinders




- 1 Collar of the belt gear
- 2 Winder axle
- 3 Coupling disks
- 4 Slipping clutch
- 5 Snap ring

Figure 5 Slipping clutches at the rewinders

1. Unplug the printer from the electrical outlet.
2. Remove the rear cover of the printer
3. Remove the snap ring (5).
4. Pull the clutch (4) from the winder axle (2).
5. Slide the new clutch (4) onto the winder axle (2).
6. Align grooves in the coupling disks (3) with the guides in the collar of the belt gear (1).
7. Slide coupling further until it stops.
8. Secure the snap ring (5).
9. Adjust the clutch ▷ 4.1 on page 4.1 on page 15.

Replacing the Brake at the Ribbon Unwinder



- 1 Pin
- 2 Spring
- 3 Winder axle
- 4 Tappet
- 5 Lever
- 6 Brake
- 7 Snap ring

Figure 6 Brake at the ribbon unwinder

1. Unplug the printer from the electrical outlet.
2. Remove the rear cover of the printer
3. Remove the snap ring (7).
4. Pull the brake (6) from the winder axle (3). Ensure that the tappet (4) remains on the winder axle. Reattach the tappet to the winder axle if it has been pulled off. The axle profile is shaped in such a way that the tappet only fits in one way.
5. Check the position of the spring (2). Ensure that the pin (1) grasps between the spring arms.
6. Slide the new brake (6) onto the winder axle (3) in such a way that it fits on the hexagonal profile of the tappet (4).
7. Push the clutch further until it stops in such a way that lever (5) grasps between the spring arms..
8. Secure the snap ring (7).
9. Adjust the brake ▷ 4.1 on page 4.1 on page 15.

3.4 Replacing the Label Sensor



Note!

Soiling of the label sensor can also cause malfunctions.

- Before replacing the label sensor, check whether it is soiled and clean it if necessary
- ▷ Instructions.



Danger!

Risk of death via electric shock!

- Before opening the housing cover, disconnect the device from the mains supply and wait at least one minute until the power supply unit has discharged.




Figure 7 Replacing the label sensor

1. Remove the material from the printer.
2. Remove the rear cover.
3. Disconnect the plug (1) from the label sensor (2).
4. Remove the screw (4).
5. Loosen the screw (5).
6. Pull the label sensor with the handle (6) out of the profile.
7. Push the new label sensor into the profile until it stops.
8. Insert the screw (4).
9. Connect the plug (1) to the label sensor (2).
10. Mount the rear cover.
11. Adjust the label sensor as required so that the marking (3) is above the label used.
12. Tighten the screw (5)
13. Calibrate the label sensor ▷ Configuration Manual > *Calibrate label sensor*.

3.5 Replacing the PCB CPU

**Danger!**

Risk of death via electric shock!

- Before opening the housing cover, disconnect the device from the mains supply and wait at least one minute until the power supply unit has discharged.




Figure 8 Replacing the PCB CPU

1. If possible, save the printer configuration to an external medium ▷ Configuration Manual.
2. Unplug the printer from the electrical outlet.
3. Detach all interface cables from the back of the printer.
4. Remove all memory media from the slots.
5. Dismount the rear cover.
6. Unplug all plug connections (3-9) from the PCB CPU (2).
7. Loosen screws (1) and remove PCB CPU (2).
8. Attach the new PCB CPU (2) with four screws (1).
9. Connect all cables to the PCB CPU (2).
10. Mount the rear cover.
11. Restore all interface connections on the back of the printer.
12. Connect the power cable.
13. Update the firmware if necessary.
14. Select the matching *Printer model* ▷ Configuration Manual.
15. Adjust the label sensor ▷ Configuration Manual.
16. Load the printer configuration from the memory medium if possible. Otherwise, set the printer configuration via control panel ▷ Configuration Manual.

3.6 Replacing the Power Supply Unit



Danger!

Risk of death via electric shock!

- Before opening the housing cover, disconnect the device from the mains supply and wait at least one minute until the power supply unit has discharged.




Figure 9 Replacing the power supply unit

1. Dismount the rear cover.
2. Dismount the PCB CPU ▷ 3.5 on page 13.
3. Unplug the cables from the connectors (3,4).
4. Loosen six screws (1) and remove the power supply unit (2).
5. Insert the new power supply unit and fix it with the screws (1).
6. Connect the cables at the connectors (3,4).
7. Re-mount the PCB CPU ▷ 3.5 on page 13.
8. Mount the rear cover.

4.1 Measuring and Adjusting the Winding Torques

The rewinders for the transfer ribbon are coupled with slipping clutches to the main drive. The supply hubs of the transfer ribbon are braked with slipping clutches during printing.

The correct setting of the torques of these slipping clutches is necessary for:

- precise conveyance of the transfer ribbon during label transport
- the prevention of wrinkles in the feed path of the transfer ribbon

The winding axes of the rewinders are not actively driven by the belts during label backfeed, but rather solely by the pull of the print roller. The torque required to disengage the rewriter from the belt drive is implemented via a brake in the winding reel, which works in both directions. The measured clockwise torque is the sum of the coupling torque and the torque of the brake. Only the torque of the brake is measured when the winding axis is rotating counter-clockwise. For this reason, measurement of the torques at the rewinders are required in both directions.

If the winding torque differs from the set value, it must be adjusted ▷ 4.1.2 on page 17.

4.1.1 Measuring the Winding Torques

Measurement of the winding torque at the transfer ribbon take up and supply hub occurs by determining the pulling forces on a test collar attached to the winder.

The physical relation between the torque and the pulling force is:

$$F = M / r$$

F: Pulling force [N],

M: Winding torque [Ncm],

r: Radius of the test collar (3 cm)

The set values for the winding torque and the resulting pulling force at the test collar are:

Winder	Measurement	Direction of rotation	Winding torque M	Pulling force F
Upper ribbon rewriter	A1	against winding direction	12,9 - 14,4 Ncm	4,3 - 4,8 N
	B1	in winding direction	2,1 - 4,2 Ncm	0,7 - 1,4 N
Upper ribbon unwinder	C1	any	3,6 - 4,5 Ncm	1,2 - 1,5 N

Table 1 Winding torques at the upper transfer ribbon winders

Winder	Measurement	Direction of rotation	Winding torque M	Pulling force F
Lower ribbon rewriter	A2	against winding direction	12,9 - 14,4 Ncm	4,3 - 4,8 N
	B2	in winding direction	2,1 - 4,2 Ncm	0,7 - 1,4 N
Lower ribbon unwinder	C2	any	3,6 - 4,5 Ncm	1,2 - 1,5 N

Table 2 Winding torques at the lower transfer ribbon winders




Figure 10 Measuring the winding torque at the transfer ribbon winders



Danger!

Risk of death via electric shock!

► **Before opening the housing cover, disconnect the device from the mains supply and wait at least one minute until the power supply unit has discharged.**

1. Unplug the printer from the electrical outlet.
2. Remove the rear cover.
3. Remove the transfer ribbon from the printer.
4. Attach the test collar (3) to the winder (2).
5. Turn the knurled nut (4) counterclockwise to clamp the test collar.
6. Wind the cord attached to the test collar around the test collar several times.
7. Secure spring scale [10 N] (1) at the end of the cord.
8. Move the spring scale upward vertically until the winder begins turning.
9. Hold the drive belt in place during the measurement. Otherwise, the measurement is not accurate.
10. Allow the cord to unwind from the test collar at least one full turn and read the pulling force F on the spring scale at the same time.
11. If the winding torque differs from the set value, it must be adjusted ► 4.1.2 on page 17.

4.1.2 Adjusting the Winding Torques

The winding torque of a winder can be changed at the knurled ring of the respective slipping clutch. The numbers on the knurled ring stand for the value of the winding torque:

- 1: Lowest winding torque
- 7: Highest winding torque

The current value is indicated by the number located at the positions of the two locking tabs.



Danger!

Risk of death via electric shock!

- Before opening the housing cover, disconnect the device from the mains supply and wait at least one minute until the power supply unit has discharged.




Figure 11 Adjusting the winding torque

1. Unplug the printer from the electrical outlet.
2. Remove the rear cover.
3. Press the knurled ring (1) of the slipping clutch toward the housing wall. The lock (2) of the knurled ring is released.
4. Turn the knurled ring while pushing it and release it in the desired position.
5. Ensure that the tabs of the lock are located completely in the grooves of the setting value.
6. Measure the winding torque again and compare it to the set value.
7. Repeat the adjustment until the measured winding torque is within the tolerance range.
Is it not possible change the slipping clutch ► 3.3 on page 10.
8. Mount the rear cover.

4.2 Adjusting the Media Feed Path

The media (1) must run between the guides (2) during the transport without a lateral drift.

The direction of the media (2) run can be adjusted by the eccentric on the deflection roller (3).




Figure 12 Adjusting the media feed path

1. Loosen the screw.
2. Turn the eccentric on the (2) internal hexagon with the hexagon key in the right position.
3. Hold the eccentric (2) and tighten the screw (5) with a second hexagon key.
4. Check the label run. If necessary adjust it again.

4.3 Adjusting the Printing Mechanism

Major adjustment of the printing mechanism beyond format-based settings is only required if the printhead assembly has been removed or parts in this area have been replaced. Excluded from this is the replacement of the printhead, after which readjustment is generally not required.

The following print quality imperfections may indicate maladjustment of the printing mechanism:

- Print image too light
- Print image is spotty
- Print image lighter on one side
- Horizontal lines not parallel to the horizontal label edges
- Clear lateral drift of the transfer ribbon



Notice!

Print image errors can also arise from wrinkling of the transfer ribbon. This is why you should check the transfer ribbon feed path and the head locking system for correct adjustment before making adjustments to the printing mechanism ▷ Instructions.

Adjustment of the printing mechanism comprises the following procedures in the order specified:


1. Preparing the printer for adjustment ▷ 4.3.1 on page 19.
2. Aligning the printhead to the print roller ▷ Table 2 on page 15.
3. Adjusting the printhead pressure ▷ 4.3.1 on page 19.
4. Adjusting the transfer ribbon feed path ▷ 4.3.4 on page 21.
5. Performing a final test ▷ 4.3.5 on page 22.



Note!

The setting of the print unit will be described for Printhead 2 (upper print unit). The setting of Printhead 1 (lower print unit) can be done in the same manner.

4.3.1 Preparing the Printer for Adjustment



1. Load labels and transfer ribbon which extend across the entire printing width
2. In the printer configuration, set the *Print speed* parameter to 100 mm/s.
3. Move the transfer ribbon deflection to the central position (1) with the screw (2).
4. Position the plungers (3) in such a way that the adjustment screws are accessible through the holes (4) of the square axis.
5. Loosen the screw (5) for the printhead bowing with an Allen key (1.5 mm) and turn it counterclockwise until turning becomes perceptibly easier. This should occur after a maximum of a half a rotation.

Figure 13 Preparing the printer for adjustment

4.3.2 Aligning the Printhead to the Print Roller

In order to achieve the best possible print image the following printhead settings are necessary:

- Setting the parallelism of horizontal lines and the edge of the label.
- Aligning the heating line to the top of the print roller. This is the position with the highest print image density.




Figure 14 Aligning the printhead to the print roller

Setting the parallelism of horizontal lines and the front label edge



Attention!

Risk of damage.

Attempting to adjust the printhead when the fixing screws (1) are tight can lead to defects at the printhead assembly.

► Always loosen the fixing screws (1) before adjusting the printhead.



Note!

► Open and close the printhead after each step of the adjustment.

1. Check the printhead alignment with the test function *Test grid* (► Configuration Manual) or a similar pattern.
2. If horizontal lines are not parallel to the label edges, loosen the screw (1) by a quarter turn and adjust the parallelism with the screw (2).
3. Tighten the screw (1).

Aligning the heating line to the top of the print roller

4. Print more test labels.
5. Set the best possible image quality by turning the eccentric (3).
Differences in the density between the two sides are still permissible.

4.3.3 Adjusting the Printhead Pressure

The printhead pressure can be changed with the screws (1a) and (1b) at the inside and outside of the printhead. Increasing the printhead pressure leads to an improvement of the print image density on the corresponding side and to a shifting of the ribbon feed path to the opposite side.




Figure 15 Adjusting the printhead pressure


1. Turn the adjustment screws (1a, 1b) counterclockwise until turning becomes perceptibly easy.
2. Reduce the *Heat level* in the printer configuration until the print image is only barely recognizable. Under these conditions, inaccuracies become clearly visible during adjustment.
3. Create print samples with the test function *Test grid* (► Configuration Manual) or a similar print pattern.
4. Adjust the adjustment screw (1a or 1b) clockwise in small increments on the side with the weaker print image until the print image is even across the entire width.
5. Set the original *Heat level* in the printer configuration.

4.3.4 Adjusting the Transfer Ribbon Feed Path

The transfer ribbon feed path can be affected by the following adjustments:

Method	Purpose
Adjusting the rear ribbon deflection	Planing the ribbon between unwinder and print unit
Fine-tuning of the printhead pressure	Avoiding wrinkles in the print zone arising from the inner or outer side
Bowing the printhead	Avoiding wrinkles in the print zone arising from the middle
Adjusting the front ribbon deflection	Adapting the feed path to the print image

Table 3 Adjusting the transfer ribbon feed path



Adjusting the rear transfer ribbon deflection

- If the transfer ribbon drifts sideways between unwinder and print unit, loosen slightly the screw (2) and adjust the rear ribbon deflection (3) by turning the eccentric (1).

Figure 16 Adjusting the transfer ribbon feed path 1




Figure 17 Adjusting the transfer ribbon feed path 2

Fine-tuning of the printhead pressure

- If the ribbon shifts to one side in the print zone, turn the screw (5a) or (5b) on the opposite side clockwise in small increments. Wait until the ribbon feed path has stabilized after each step of the adjustment.

Bowing the printhead



Attention!

The printhead assembly can be damaged when bowing the printhead.

Turning the adjustment screw (7) too hard can cause damage to the printhead assembly.

- As soon as you perceive clear resistance when turning the adjustment screw (7), you may only continue turning the screw in very small increments, but no more than one eighth of a turn.
- Only turn the adjustment screw (7) as far as is absolutely necessary.
- If the wrinkles cannot be remedied (e.g. wrinkles in the center), turn the adjustment screw (5) clockwise **with extreme care** using an Allen key (1.5 mm) and observe the ribbon feed path. When the adjustment screw (7) is tightened, the printhead is bent downward slightly in the center. It is possible that a slight lightening at the edge areas of the print image could occur here.
- If bowing is not necessary, turn the screw (7) clockwise until the screw is just barely clamping.

Adjusting the front transfer ribbon deflection (6)

- Turn screw (4) with Allen key and observe the behavior of the ribbon. If wrinkles arise from the inner side turn the screw counterclockwise, if wrinkles arise from the outer side turn the screw clockwise

4.3.5 Final Test

- Recheck the setting with the test function *Test grid* (► Configuration Manual) or a similar print pattern.

When using standard cab media, the test printout must show lines with sharp contours and black areas without any parts missing.

4.4 Adjusting the Automatic Ribbon Saver

The lower print unit 1 is equipped with an automatic ribbon saver.

The ribbon saver reduces the consumption of transfer ribbon by lifting the printhead while feeding blank label areas. The printhead will be lifted by eccentrics and the ribbon unwinder will be blocked by a magnetic clutch.

	Print phase	Saver phase
Eccentrics	Printing position -> Printhead is pressed down	Saving position -> Printhead is lifted
Magnetic clutch	Off -> Ribbon unwinder can be turned	On -> Ribbon unwinder is blocked

Table 4 Phases of the saver mode

4.4.1 Setting the Eccentrics

With a misalignment of the eccentrics the printhead will never be lifted although the ribbon saver is switched on.

1. Lock the printhead.
2. Switch on the printer.
The ribbon saver will be synchronized.



Access to the following functions only with service key installed!

3. Check the movement of the eccentrics by changing between print and saver position using the function *Setup > Ribbon > Toggle ribbon saver*.
Thereby the printhead must be lifted and lowered.
4. If the printhead is not be moved invert the setting of *Setup > Ribbon > Invert eccentric position*.

4.4.2 Adjusting the Magnetic Clutch

A misaligned magnetic clutch can cause a very high and not adjustable torque at the ribbon supply hub. The distance between chassis of the magnetic clutch (4) and the armature disk (3) must be 0.1 mm .



Danger!

Risk of death via electric shock!

► Before opening the housing cover, disconnect the device from the mains supply and wait at least one minute until the power supply unit has discharged.




Figure 18 Adjusting the magnetic clutch

1. Unplug the printer from the electrical outlet.
2. Remove the rear cover.
3. Loosen three set screws (2).
4. Pull armature disk (3) to the slipping clutch.
5. Insert the distance caliber 0.1 mm (1) between armature disk (3) and chassis of magnetic clutch (4) .
6. Slide armature disk (3) to the chassis so that the distance caliber (1) will clamp slightly and tighten the screws (2).
7. Remove the caliber.
8. Adjust the torque at the ribbon supply hub.
9. Mount the rear cover.

5.1 Failure of Device Functions

Functional error	Possible remedy
Medium is not transported	Check electrical connections between PCB CPU and motor
	Check drive mechanism
	Replace the PCB CPU
	Replace the motor
No print image with medium transport	Check plug connections at the printhead
	Examine printhead cable for damage and replace if necessary
	Check the automatic ribbon saver
	Replace the printhead
	Replace the PCB CPU
No display function	Check cable connection between PCB CPU and control panel
	Replace the control panel
	Replace the PCB CPU
Communication via an interface is not functioning	Check whether the interface configurations of the printer and computer match
	For an Ethernet connection, check the validity of the IP address and the subnet mask
	Check the interface cable and replace it if necessary
	If all functionality of the interface has been lost, replace the PCB CPU

Table 5 Failure of device function

5.2 Permanent Hardware Faults

Error message	Cause	Fault recovery
<i>Printhead thermistor broken</i>	Thermistor at the printhead defective	Replace the printhead
<i>Voltage error</i>		
V_{BAT}	Voltage of the battery on the PCB CPU is too low	Replace the PCB CPU
24 V	24 V too low	Check voltage at measurement point +24V ▷ Figure 22 on page 27: - Voltage too low: Replace the power supply unit - Voltage is correct: Replace the PCB CPU
24 V TPH	24 V for the printhead too low	Check voltage at measurement point +24V TPH ▷ Figure 22 on page 27: - Voltage too low: Replace the power supply unit - Voltage is correct: Replace the PCB CPU

Table 6 Hardware faults




Figure 19 Block Diagram XC Q




Figure 20 Layout diagram PCB CPU X4.3

Measuring points at CON9:

◇	GND
◇	+24V
□	+V _{MOT} (+24V)

Measuring points on the PCB:

○	TOP2	+24V
○	TOP3	+5V
○	TOP25	+24V TPH
○	TOP26	+V _{MOT} (+24V)

LEDs on the PCB:

○	H1	+3,3V
○	H7	LED FPGA on during start procedure blinking after start procedure

A

Adjusting the printing mechanism.....19
Automatic ribbon saver adjustment ..23

B

Bowing the printhead.....22
Brake ribbon unwinder..... 11

E

Eccentrics23
Environment5
Error treatment25
Exzenter 18

G

General safety instructions4

H

Hardware faults25

I

Important information.....4

M

Magnetic clutch.....24
Maintenance work5
Measuring points27
Media Feed Path 18

P**PCB CPU**

Layout diagram27
PCB CPU replacement.....13
Power supply replacement14
Printhead position.....20
Printhead Pressure.....21
Printhead pressure adjustment.....21
Printhead replacement7
Print image19
Printing mechanism.....19
Printing Mechanism.....19
Print roller replacement9
Protective devices5

R

Rewinder 11, 16
Ribbon Feed Path.....21

S

Safety instructions4
Slipping clutches
Adjustment.....17
Replacement.....10

T

Test collar 15
Torque..... 15
Transfer ribbon21
Transfer Ribbon.....21
Transfer ribbon feed path19, 21

U

Unwinder 11, 16

V

Voltage error25
Voltages, exposed5

W**Winding torque**

Adjustment.....17
Measurement.....15